

## HID FIXTURES WITH CM3 CANOPY INSTALLATION INSTRUCTIONS - SAVE THESE INSTRUCTIONS

**CAUTION:** Read and understand these entire instructions before proceeding.

**CAUTION:** Installation should be performed by qualified electricians only.

**CAUTION:** Install per National Electrical Code and any local codes that may apply.

**CAUTION:** Do not install in wet locations.

**CAUTION:** Use only with a grounded power supply.

**CAUTION:** Disconnect power before installing.

INSTALLATION INSTRUCTIONS (See Diagram 1 for parts identification) - NOTE: SEE SEPARATE INSTRUCTIONS FOR INSTALLING THE FIXTURE TO THE STEM, AND THE STEM TO THE CANOPY (IF A STEM IS REQUIRED). THIS MUST BE DONE PRIOR TO FOLLOWING THE INSTRUCTIONS BELOW.

1. Remove the 3 canopy screws from ceiling plate and the 3 lock nuts from the ballast plate. Set these items aside.
2. Pull all feeder wires through the center hole of the ceiling plate.
3. Attach ceiling plate to outlet box with outlet box screws (supplied by others).
4. Attach green ground wire on ceiling plate to system ground. Tuck this wire up into outlet box.
5. Attach ballast plate to canopy plate with lock nuts from Step 1. Make certain that nuts are tight, and that *all* system feeder wire ends are accessible after the ballast plate is attached.
6. Connect system feeder wires to the AC Input ballast wires (BLACK or BROWN = HOT & WHITE or BLUE = NEUTRAL).
7. Hang canopy (with fixture attached) from S-Hook on driver plate as shown.
8. Connect the fixture wires to the ballast wires as shown in Diagram 2 .
9. Carefully install canopy to canopy plate using the 3 screws from Step 1.

