

## ADJUSTING WIRE LENGTH:

1. Unscrew strain relief cap.
2. Raise cap at least 2" up socket wires.
3. Spread strain relief grips.
4. Gently pull (or push) socket wire into strain relief base.
5. Slide cap as far down as it will go, and
6. Fully screw cap back onto strain relief base.

