

LED FIXTURES WITH CM3 CANOPY INSTALLATION INSTRUCTIONS

- SAVE THESE INSTRUCTIONS

CAUTION: Read and understand these entire instructions before proceeding.

CAUTION: Installation should be performed by qualified electricians only.

CAUTION: Install per National Electrical Code and any local codes that may apply.


CAUTION: Do not install in wet locations.

CAUTION: Use only with a grounded power supply.

CAUTION: Disconnect power before installing.

INSTALLATION INSTRUCTIONS (See Diagram 1 for parts identification)

1. Remove the 3 canopy screws from ceiling plate and the 3 lock nuts from the driver plate. Set these items aside.
2. Pull all feeder wires (and any system control wires, if applicable) through the center hole of the ceiling plate. NOTE: System control wires would be for 0-10V dimming, LUTRON® EcoSystem® dimming, DMX/RDM, etc.
3. Attach ceiling plate to outlet box with outlet box screws (supplied by others).
4. Attach green ground wire on ceiling plate to system ground.
5. Attach driver plate to canopy plate with lock nuts from Step 1. Make certain that nuts are tight, and that *all* system feeder wire ends (and system control wire ends, if applicable) are accessible after plates are attached.
6. Connect system feeder wires to the AC Input driver wires (BLACK or BROWN = HOT & WHITE or BLUE = NEUTRAL, or follow instructions on driver label for these connections if such a label is present). If 2 BLACK wires are present, the one in close proximity to the WHITE wire = HOT.
7. Connect any system control wires (if present) to the appropriate driver wires. NOTE: See Table 1 for assistance in making these connections.
8. Hang canopy (with fixture attached) from S-Hook on driver plate as shown.
9. Connect the sleeved canopy wires to the driver wires as shown in Diagrams 2 or 3. NOTE: Diagram 1 is for fixtures with 2 sleeved wires. Diagram 3 is for fixtures with 4 sleeved wires. NOTE: Wires from fan power supply (if provided) are delicate and must be handled with care!
10. If the canopy has an integral potentiometer, connect the 3 potentiometer wires to the 3 appropriate driver wires. NOTE: Each color wire on the potentiometer must match the color of the connecting wire on the driver.
11. Carefully install canopy to canopy plate using the 3 screws from Step 1.



0-10V DIMMING		
DRIVER WIRE COLOR	CONNECTS TO	CONTROL WIRE COLOR
VIOLET	CONNECTS TO	VIOLET
GREY	CONNECTS TO	GREY
STANDARD LUTRON® EcoSystem®		
DRIVER WIRE COLOR	CONNECTS TO	CONTROL WIRE COLOR
VIOLET	CONNECTS TO	VIOLET
VIOLET / WHITE	CONNECTS TO	VIOLET / WHITE
DMX/RDM		
DRIVER WIRE COLOR	CONNECTS TO	CONTROL WIRE COLOR
ORANGE	CONNECTS TO	ORANGE (DATA-)
ORANGE / WHITE	CONNECTS TO	ORANGE / WHITE (DATA+)
BROWN	CONNECTS TO	BROWN (COM)
NOTE: FOR CONTROL SCHEMES NOT LISTED ABOVE, REFER TO SEPARATE SUPPLIED DOCUMENTAION		

